

# Direct Connect 401

Quick Start Guide

## Set up


To get started with your Direct Connect, follow steps on this manual.

### Here is what you will need:

- Direct Connect DC 401
- Station Internet Service (Using internet service provided by Petroleum)
- Personal Laptop or Desktop Computer (at the station)
- Activation Code


## In this Package

### DC-401 Box




- 01 – LAN Port 1    03 – Power Cable  
02 – LAN Port 2    04 – Power Button

### AC Power Adapter



### Ethernet Cable



# Installation

- 01 Connect the Network Cable to the LAN Port on your DC Box.
- 02 Connect your laptop to the LAN port on your DC Box using the Ethernet cable.
- 03 Plug your DC Box in to an outlet/power source using the Power Cable.
- 04 Press the Power Button to start your DC Box.

Finishing up, you will be routed to the "Health Monitoring" page that will automatically update the status of the POS and Petrosoft Cloud.

If you have other issues, contact [helpdesk@petrosoftinc.com](mailto:helpdesk@petrosoftinc.com)

# Helpful Tips

You can always access this page via <http://10.10.2.1/status>

- Log in using username: **admin** password: **SwHH3g**
- If you get stuck, on any step you can re-start the process by going back to the first step. <http://10.10.2.1>
- If you need additional info you can connect to the Monitor via HDMI cable to see additional status info
- If box does not respond on the proper IP adress you can reset network configuration by pressing POWER 5x.
- To get additional info you can connect the DC Box to your monitor via HDMI or VGA cables. The DC information screen will be available. This screen will help you to proceed with activation and set-up the SIN & WAN ports.

