

Connect 1202 Scanner to Base

If your 1202 barcode scanner emits 3 consecutive beeps, it indicates that the scanner has lost its connection to the USB base. Follow the steps below to reconnect the scanner to the base.

1. Disconnect the USB cable from the SmartPOS device.
2. Scan the barcode below.



3. Connect the USB cable to the SmartPOS within 30 seconds. If the beeping stops immediately, the pairing was successful.

Once these steps are completed, the handheld scanner will be reconnected to the base. You can then reprogram the scanner to work with SmartPOS.